













cataC









2






3





2x P4



















ES: Vaciar después de cada cocción o después de 2h de cocción intensiva.
 EN: Empty after each cooking session or every 2 hours of intensive cooking.
 FR: Vider après chaque cuisson ou toutes les deux heures de cuisson intensive.
 PT: Esvaziar após cada cozimento ou a cada duas horas de cozimento intensivo.
 DE: Nach jedem Kochvorgang oder alle zwei Stunden intensiven Kochens entleeren.




OPTIONAL ACCESORIES



02800013



HOOD A: 02859398
 HOOD B: 02859318



REAR OUTLET:
 02800014



CATA ELECTRODOMÉSTICOS, S.L.

Oficinas: c/ Anabel Segura, 11, Edif. A, 3a pl. 28108. Alcobendas. Madrid. España

Fábrica: c/ del Ter 2, Apdo. 9. 08570. Torelló. Barcelona. España

T . +34 938 594 100 - Fax +34 938 594 101

www.cnagroup.es - cna@cnagroup.es

Atención al Cliente: 902 410 450 / +34 938 521 818 - info@cnagroup.es
International SAT - www.cnagroup.es/warranty

